k.™ task

Operating Instructions

k. task is a highly adjustable work chair well-suited for the demands of today's workplace.





Design Features

+ Double-layer mesh back

Combines the comfort of a knit with the rigidity of mesh for ongoing support.

+ Waterfall seat edge

Promotes circulation and allows for shifting postures.

Intuitive Adjustments

Seat height

To lower seat, lift the right lever while seated in the chair. To raise seat, remove your weight from seat while lifting right lever. Release to lock.

Seat depth

Lift the left lever and slide to the desired position. Release to lock

3 Tilt tension

Turn right knob forward to increase the tilt tension or backward to reduce tension

4 Five-point tilt lock

Turn left knob backward to lock upright or forward to allow for recline. To set recline lock position, lean back and turn knob backward at any point or at full recline. This will lock chair in the next closest position. To release, turn knob forward, recline slightly and sit back upright.

Performance Options

6 Height adjustable arms

To adjust the height, push the button underneath the armpad. Slide the arm to the desired position and release the lever to lock.

6 Optional Lumbar

To adjust the height, pull tab up or down along the back. To adjust in depth, turn the knob clockwise to tighten or counter clockwise to loosen.

Note: See these operating instructions on the pull out tab on the left side of the seat, indicated with the Knoll logo.

